



10. Select to save current configuration and reboot

Once the device restarts you are now ready to start using your iSage VoIP service.